



SHIFT CABLE SECURITY CLIPS — 986 / 996

Clip orientation, original clamp removal where specified, and safety pin installation.

986 / 996

2 steps | Updated Sep 10, 2026



IN THIS GUIDE

Installation

[View the current guide online](#)

Installation

I

REMOVE THE ORIGINAL THREE-PRONG CLAMPS

INSTALLATION INSTRUCTIONS FOR 986/996 SHIFT CABLE SECURITY CLIPS

Once you have access to the shift cable links attached to the transmission, you will notice a 3 prong clamp attached to each (see photo below). It is necessary to remove these clamps from the shift cable links. They are easily removed by prying them off gently from each tab (3 tabs).

****Photo shown shows original clamps****

****These are the clamp(s) that need to be removed****



INSTALLATION INSTRUCTIONS FOR 986/996 SHIFT CABLE SECURITY CLIPS

Once you have access to the shift cable links attached to the transmission, you will notice a 3 prong clamp attached to each (see photo below). It is necessary to remove these clamps from the shift cable links. They are easily removed by prying them off gently from each tab (3 tabs).



****Photo shown shows original clamps****



****These are the clamp(s) that need to be removed****

Step 1 - Remove the original three-prong clamps (continued)

Original instruction sheet — page 1. [Select the image to enlarge.](#)

2**INSTALL THE SECURITY CLAMPS AND SAFETY PINS**

Once you have the original clamps removed, it is time to install the TRS security clamps. The clamps slip over the shift linkage. You should have 8 safety pins that came with the kit and 4 security clamps. Each clamp uses two safety pins. Slide the pins through the holes in the security clamps and spread them so that they lock in place (see photos below). Once you have done that, you are all set.

For more information, please contact TuneRS Motorsports at 954.345.7877 or info@tunersmall.com

Step 2 - Install the security clamps and safety pins (continued)

Once you have the original clamps removed, it is time to install the TRS security clamps. The clamps slip over the shift linkage. You should have 8 safety pins that came with the kit and 4 security clamps. Each clamp uses two safety pins. Slide the pins through the holes in the security clamps and spread them so that they lock in place (see photos below). Once you have done that, you are all set.



For more information, please contact TuneRS Motorsports at 954.345.7877 or info@tunersmall.com

Step 2 - Install the security clamps and safety pins (continued)

Original instruction sheet — page 2. Select the image to enlarge.

NEED A HAND WITH YOUR INSTALLATION?

Contact TuneRS for product questions or help finding the right installation guide.

(954) 345-7877 | info@tunersmall.com